

nobü®  
the essence of pleasure

ENGLISH

Instruction manual for these products

SWANI UNO DUCKY  
BOTA WAVY TIGO

### ■ ■ SAFETY ISSUES

Avoid sharing this personal object with others due to hygiene concerns.  
Stop using this device immediately if you feel uncomfortable using it. Water based is the only lubricant recommended to be used with this product. Be cautious when using your device for anal insertion. Stop using this device if its tip is chipped or broken or has sharp edges. Please do not use massage oils or hand cream as lubricants for this device, as you will damage its silicone soft touch surface. Please keep this device out of children's reach.

### ■ ■ HOW TO USE

- 1 - Please charge fully before first use.
- 2 - The use of a condom with this device is highly recommended.
- 3 - Press ON/OFF button for 2 seconds to turn on.
- 4 - After pressing the ON/OFF button for 2 seconds, press the upper or lower triangle to activate a vibration mode. In total you can choose from 10 different programs.

**To turn off your vibrator please press the ON/OFF button for 2 seconds.**

### ■ ■ PRODUCT BRIEF

The streamline is specifically designed to fit perfectly with a woman's intimate anatomy in mind for maximum comfort!  
The advanced USB charging system is not only very convenient to use, but it also permits the entire vibrator to be completely waterproof and easy to clean! The heavy duty Li-ion battery allows you to enjoy your vibrator for over 2 hours between charges.  
The medical grade silicone and ABS used for all nobü® intimate vibrators gives you the assurance that these products are totally safe for your body, and the velvet finish give you that extra soft touch!


### ■ ■ SPECIFICATIONS

User: Female  
Battery type: Li-ion  
Number of pulsation modes: 10 Tri-band frequency vibration sensor  
User time: More than 2 hours  
Water resistant: 100% waterproof  
Materials: Silicone + ABS

### ■ ■ FIGURE A

- 1 - Press ON/OFF (Press for 2 seconds).
- 2 - Press the up or down triangle button to select one of the 10 available programs.

**To turn off your vibrator please press the ON / OFF button for 2 seconds.**



### ■ ■ SERVICE

Your nobü® Vibrator is an extremely well designed and assembled device, using only the best materials on the market and should procure you many years of pure worry free pleasure.

However, If you experience any problems or factory/assembly defects or you need additional information to operate your device please contact our service department and we will do our best to solve your issues as soon as possible.

Caution: please do not take your vibrator apart by yourself or by an unauthorized repair shop, as your warranty will automatically expire.

### ■ ■ DISCLAIMER

Users of this device are doing so at their own risk. Neither nobü® Toys nor its retailers are responsible for any injury caused by the use of this product. This is to be used as a novelty item only!

This product doesn't claim to cure any disease or STI.

### ■ ■ CLEANING AND STORAGE

Always clean your nobü® Toy thoroughly before and after each use. Clean your device with an antibacterial toy cleaner.

Hard detergents, disinfectants, acetone or 75% alcohol are not recommended to clean your device.

Avoid direct sunlight and air dry your device.

Store your device in a clean and dry space, and avoid leaving it in contact with other silicone or TPR devices, as this could affect the properties of the high grade ABS of your device.

*For all inquiries, including repair and service please contact us at:*

Bodispa inc.

World headquarters

2150 Ward street,

St Laurent, Quebec, Canada, H4M-1T7

Tel : 514 855 0045

Toll free from North America: 1 800 465 5822

Email: info@bodi-spa.com

CE FDA RoHS