

BODISPA™

THE POWERWAND

100% WATERPROOF




Designed for maximum pleasure intensity with minimal noise

GETTING STARTED


Congratulations on your purchase. Follow these simple steps and you will be enjoying a luxurious massage in no time.

- With First time use, the POWERWAND is Factory pre-charged with 50% power available.
- Press the "Ⓜ" to turn ON the POWERWAND. This button controls the "ON -OFF" Function.
- You can now activate a choice of 10 different vibration intensities by pressing the "Ⓜ" button (above the "on-off" button). Continue pressing "Ⓜ" to choose/adjust the intensity you desire.
- To turn OFF the POWERWAND, simply press the "Ⓜ".



CHARGING YOUR VIBRATOR

- When the vibrations become weak, or stop completely, and the LED light is still on, the POWERWAND needs to be re-charged.
- Insert the DC plug into the DC port on the underside of your POWERWAND (see illustration below).
- Insert the other end of the DC recharging cord into any wall socket. The red LED will light-up to indicate it is recharging. When it is Fully charged (after 2 hours), the light goes out.



BENEFITS OF REGULAR MASSAGER USE

- A choice of ten vibration levels offers the user varied levels of massage intensity to areas of discomfort from muscle tension, aches and pains. Gentle or strong, the choice is up to you.
- A GENTLE MESSAGE will stimulate your skin's nerve endings which can result in an increased release of your body's endorphins, which naturally calm and relax you. Your stress levels decrease as your breathing and heart rate slow down and you become increasingly relaxed.

- A STRONG MESSAGE will increase blood circulation, resulting in increased oxygen and nutrients to the massaged area. The increased circulation will also help to flush waste towards your lymphatic system, which in turn assists your body's over all health and well being.
- You may also enjoy a more relaxing massage in the bath or shower, where warm water will also relax your muscles and make them more receptive to stimulation.

NOTE

- The POWERWAND body massager is not classified as a medical device. Do not massage around your chest or throat area, and if you experience severe discomfort during the massage, you should stop using the POWERWAND and consult your healthcare provider.

SPECIFICATIONS

SIZE: 300*50*20mm

WEIGHT: 430g

MATERIALS: Glossy ABS/FDA-Approved Body-safe silicone

BATTERY: Li-Ion 1020mAh 3.7V

CHARGING: 3 hour at 5V 500mA

USER TIME: Up to 3 hours Depending on Power Setting

MAX NOISE LEVEL: <60dB

CLEANING, STORAGE, AND SAFETY

- You can wash the silicone section with warm water and antibacterial toy cleaner. Rinse with clean hot water and pat dry with a lint-free cloth or towel. Never use cleansers containing alcohol, petrol or acetone.
- Store your POWERWAND in a clean, dry dust-free place. Avoid leaving it in direct sunlight and NEVER expose it to extreme heat.

BODISPA™

THE POWERWAND